

Instructions For:

CE-POP - Banner with Pop-Up Stand



Product Specifications

Visible Graphic: 24" x 70"
Total Graphic Print Size: 24" x 70"
Banner Requires #2 Grommets in each corner
Foot Print Dimensions: 16" x 36"

Product Parts

- 1 - Hub and Bottom Legs
- 2 - Arms




Step 1

Remove all parts from the bag. Place the unit on the ground/work surface

Step 2


Rotate the Bottom Legs (1) to the extended position.



Step 3

Slip each Arm (2) into the holes on the top of the Hub (1). Rotate the leg bases (in yellow) to the extended position, being sure that the hooks on the Arms (2) face the same direction as those on the Bottom Legs (1).

Lay the assembled unit face up on the floor.



Note: Ensure the Arms are pressed firmly & all the way into the Hub. If the arms are loose both the Arms and the Hub can be damaged.

Step 4

Lay the banner flat, printed side up, on top of the banner stand. Slip the grommets onto the hooks on each corner. The Stand will need to bend, which will pull the banner taut. Stand the unit upright, and rotate the back leg outward to support the stand.

Gently bend Arms (2) when attaching banner.

Caution: Do not force a smaller than recommended banner on the display as it may cause damage to the unit.

